



Woodplank Infinity

Care and Maintenance

- WOODPLANK façade products are DESIGNED to use little or no maintenance.
 - WOODPLANK products could be washed with soap and water using a soft brush and a ph detergent range between 5-7.. DO NOT use any MEK or any other paint removal chemical in order to avoid appearance defects.
 - For best looking results is recommended to wash the surface every 14-18 months in typical urban and rural environments. In areas of high pollution such as industrial, high traffic commercial areas is recommended to clean the surface every 4-6 months. In coastal environments, beach fronts is recommended to gently clean the surface every 2-4 months.
 - Cleaning is recommended for best looking, new appearance of the product and not for its protection.
 - In case of painting around the WOODPLANK products and overspray has touch the products, clean the surface with water and soap, do not use any paint removal products such as paint thinner, MEK or other chemicals such as acidic, alkaline, or alcohol based products. Use a soft sponge to remove the overspray surface.
-